















































2010 F01 BMW = Fuses in Glovebox



No.	1	2	3	4	5	7	8	9	10	11	12	13	14	15	16	17	18
Ampere	10	5	5	5	10	30	30	30	10	7.5	5	5	15	15	40	30	30
No.	19	20	21	22	23	24	25	26	27	28	29	31	32	33	34	35	36
Ampere	20	20	30	30	5	10	5	-	5	15	7.5	5	7.5	5	5	15	30
No.	37	38	39	40	41	42	43	44	45	46	47	48	50	51	52	53	54
Ampere	30	40	40	30	-	30	5	5	5	5	20	5	-	30	30	30	20
No.	55	56	57	58	59	60	61	62	63	64	65	66	67				
Ampere	20	5	-	5	10	5	20	15	10	7.5	15	7.5	10				

	2,35,40, 43,60,180		2,8,14,15,32, 110,114,143, 144,149		35,132, 195,202
	1,13,24,39,43,45, 134		7,8,9,17,18,32		135,139,184
	19,100,145,148		187,188		20,21,22,35,42, 47,59
	4,8,10,13,24,25, 31,44,113,118, 120,121,123,124, 131,140,170,200		27,31,32,52,53, 67,112		
START STOP	33,38,56,103, 136,190		33,198,199		152,182
	8,32	OBD	3		168
	34,37,45,107,118		121,177,181		4,28,105,118, 120,170,189,200
 4x4	63,64,138,178		46		139
			8,51,55		8,36
 	8,13,16,66, 101,154		203,204		8,36
	10,13,154		8		153,155,183
	29		44,48,142		58,61
	58,169		5,13,48,58,66		23,27,117
	8		34,37,45		100,109,151
	43,46,121,128, 137		8,12,13		58,61
	8,62		8,11,31,44,156		54,65,147,176

Fuse-Box.info